

3 SECTION
SLIDE-UP CAR DOOR
INSTALLATION GUIDE

(Single Counterweight)



THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

Contents

1.	FORWARD	1
2.	BEFORE STARTING INSTALLATION	1
3.	JOB NUMBER IDENTIFICATION	1
	HANDING	
5.	3 SECTION SLIDE-UP CAR DOOR ASSEMBLY	3
	CAR DOOR & RETIRING CAM INSTALLATION NOTES	
	6.1. GENERAL	4
	6.2. CAR DOOR RAILS & BRACES	
	6.3. CAR DOOR PANELS	
	6.4. CAR DOOR MOTORIZED SHEAVES OR MANUAL SPROCKETS & IDLER SPROCKETS	5
	6.5. CAR DOOR COUNTERWEIGHT	5
	6.6. CAR DOOR CHAINS AND CHAIN STUDS	5
	6.7. CAR DOOR RUBBER BUMPERS	6
	6.8. CAR DOOR CONTACT	6
	6.9. RETIRING CAM	
	6.10. PULL STRAPS	7
7.	CAB / CAR ENCLOSURE PREPARATION	8
8.	RAIL INSTALLATION	9
	SPREADER / OPERATOR SUPPORT	
10.	RAIL SPREADER & DIAGONAL BRACE	11
11.	GAUGE THE RAILS	. 12
12.	SET THE RAILS	. 13
13.	BRACING RAILS TO CAR	14
14.	COUNTERWEIGHT ASSEMBLY	. 15
15.	COUNTERWEIGHT INSTALLATION	. 16
16.	IDLER / ENCODER INSTALLATION	. 19
17.	OPERATOR / SPROCKET INSTALLATION	.20
18.	PANEL BUMPERS	21
19.	UNLOADING THE PANELS	22
20.	INSTALL THE UPPER PANEL	23
21.	INSTALL THE MIDDLE PANEL	24
22.	INSTALL THE LOWER PANEL	25
23.	CHAIN CONNECTION DETAIL	26
24.	PANEL ROPING SCHEMATIC	27
	CHAIN CONNECTION DETAILS	
26.	REMOVE COUNTERWEIGHT STOP ANGLE	.30
	PULL STRAP INSTALLATION (MANUAL OPERATION)	



Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

Date: Nov 22 / 2019

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

28.	CAR DOOR / CAR DOOR CONTACT	.32
29.	RETIRING CAM TOP ASSEMBLY	.33
	RETIRING CAM BOTTOM ASSEMBLY	
31.	RETIRING CAM ROD INSTALLATION.	.35
32.	FILLER ANGLES.	.36
	GOF MICRO SWITCH INSTALLATION.	
34.	CAR DOOR PROXIMITY SENSOR (OPTIONAL).	.38
	DOOR PROXIMITY SENSOR (OPTIONAL)	



Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

FORWARD 1.

The following Installation Guide is for a standard Peelle product assembly. However, Peelle products are designed-built to suit many elevator conditions such as very large openings, limited elevator shaft dimensions, hoistway conditions and unique lift designs. Therefore special designs, arrangements or add-ons may not be covered in this manual. Refer to the installation drawings provided with your order for instructions on special components or arrangements.

If you have any questions, concerns or require further details regarding your installation please call 1 (905) 846-4545 x 275, please have your Peelle Job Number handy. A Peelle technical support expert will help you save time and keep the installation moving.

2. BEFORE STARTING INSTALLATION

- 1) You will require a moving platform
- 2) This is a two person job
- 3) Safety Equipment
 - ➤ Personal Protective Equipment
 - ➤ Workplace Barricades
 - ➤ Fall Protection
- 4) Tools required

☐ Measuring Tape
Level
☐ High Speed Drill
☐ Drill Bits HSS 5/16" [8mm] & 3/8" [10mm]
☐ Impact Wrench
☐ 9/16" [14mm] socket
☐ Angle Grinder

- Chain Pin Extractor (Chain Breaker) (Peelle Part No. 0608)
- Open and closed ended wrenches (3/8" to 7/8") [10mm to 22mm]
- ☐ Socket set (3/8" to 7/8") [10mm to 22mm]
- Screwdriver Set
- Pliers
- 5) Hardware kits included
 - ➤ Peelle Part No. 060133 Standard car door hardware kit
 - ➤ Peelle Part No. 02321 Counterweight shoe hardware

3. JOB NUMBER IDENTIFICATION

- ➤ Locate the peelle job number on the rails, car door panel and counterweight.
- ➤ Job numbers should match and include the line designation
- **Example:**

104844 GPA

104844 = Job NumberGP = Gate PanelA = Front Line (C = Rear Line)




FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

Nov 22 / 2019 Date:

4. HANDING


➤ Instructions shown here are typical for a car car door with a Peelle right hand mounted interlock and retiring cam. For left hand installations opposite configuration will be used.



PLAN VIEW OF HOISTWAY

Guide No. 218-EN3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

3 SECTION SLIDE-UP CAR DOOR ASSEMBLY 5.





Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

6. CAR DOOR & RETIRING CAM INSTALLATION NOTES

6.1. GENERAL

Install car doors after the landing doors are installed. Car doors are counterweighted with a counterweight traveling on the outside of the car door rails. Refer to the Car Door Assembly Drawing for a component breakdown. Where the overhead space is limited, the car door is made in two sections or three sections.

Overhead/headroom height is the area of a hoistway shaft extending up from the sill of the highest landing to the nearest obstruction above in the hoistway shaft. A two-section (telescopic) car door is used when over-head space will not allow a single section car door. The two sections of the car door are coupled, with the lower panel traveling twice as fast as the upper panel. This enables both sections to reach the open position simultaneously.

CAR DOOR TYPES (VERTICAL-SLIDE-UP TYPE):

- ➤ Single-section available overhead space.
- ➤ Two-section (Telco) limited overhead space.
- ➤ Three-section (Telco) extremely limited overhead space

PANEL CONSTRUCTION

- ➤ Solid Panel
- ➤ Wire Mesh (option to save car weight)

If installing both a front car door and a rear car door, make sure they are installed at proper front or rear locations to allow the retiring cams to operate the door interlocks. Do not switch the front and rear car doors. The hands (LH & RH) of a retiring cam, car door counterweight and all hardware are as viewed from inside the car looking out. The retiring cam is on one side (either right or left hand) of the car door and the counterweight is on the other side (the other hand).

6.2. CAR DOOR RAILS & BRACES

Before installation of the rails, measure the distance from the front of the elevator platform to the car enclosure angles. If not enough space has been provided between the front of the platform and the car enclosure angles, it will be necessary to cut back the cab side walls and relocate the car enclosure angles. Be sure of your measurements before you do any cutting. The car enclosure angles are usually 50mm by 50mm by 5mm [2in x 2in x 3/16in] steel angles and should have holes to attach the car door rails.

Install the car door rails. Bolt them to the platform and to the car enclosure angles. Make sure the rails are plumb and square. Hold the correct distance-between-guides so the car door will fit. Use "Distance Between Guides" (DBG) dimension located on the Gauge Rod.

After installing both sets of car door rails, attach the top spreader, brace angle and diagonal brace. The top of the car door is held in place by two brace angles connected to the elevator cross-head. The distance between the car door rails must be constantly maintained when the spreader and braces are installed. Bolt braces tightly after car door panel is installed and adjusted.



Guide No. 218-EN3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

Check the overhead / headroom space for interference, then run the car up slowly on inspection to the top floor and check overhead / headroom for code clearance of car door rails and braces, and run by.

6.3. CAR DOOR PANELS

To install the car door panels, remove the shoes on either side, move the car door into its guide tracks while sliding on the platform. Then reinstall the shoes.

Install the upper panel first and hold in place using wood braces. Next install the middle and lower panels in the closed position.

6.4. CAR DOOR MOTORIZED SHEAVES OR MANUAL SPROCKETS & IDLER SPROCKETS

Power car door operators have a combination sheave and motor while manual car doors have a double sprocket assembly that bolts into the pre-drilled rail location on the counterweight side. The single sprocket idler assembly is mounted inside the opposite rail.

6.5. CAR DOOR COUNTERWEIGHT

The counterweight travels on the outside of the car door rail. The counterweight requires two supporting chains. Carefully hoist the counterweight to the top of the car. Lower the counterweight into the guide track so that it rests on the temporary support angle near the top of the guide track.

6.6. CAR DOOR CHAINS AND CHAIN STUDS

Attach the two counterweight chain-studs 100mm [4in] long to the counterweight. Attach the chains to the chain-studs. Wrap connecting links and connector clips at each end of the chain with the nylon tie-wraps provided. Wipe any excess oil off the chains.

Remove extra links from end of chain and connect the longer chain studs 180mm [7in]. long to the loose ends of the chains and then connect these chain studs into their hangers on the car door panel. Secure the chain connecting links with nylon tie wraps. Each chain stud gets 2 nuts, a lock washer and a cotter pin. Make sure the nuts are almost touching the cotter pin near the bottom of the chain stud. This allows for the easy future chain stretch adjustment.

Connect the lower panel chains the counterweight. The long chain connects to the counterweight over the operator across to the idler and down to the panel. The other chain connects from the counterweight over the operator and down to the panel.

Connect the middle panel chain to the dead end hitch at the top of the upper panel. Connect the other end of the chain around the middle panel sheave and to the lower panel chain pickup.

Connect the upper panel chain to the chain stud in the holes provided in the top spreader. Connect the other end of the chain around the upper panel sheave and to the middle panel chain pickup.

After attaching the chains to both the counterweight and car door panel, remove the temporary support angle. Manually lift the car door to full open. Have it touch the upper bumper stops. At this position, the bottom edge of the car door should be even with or slightly above the car enclosure



Guide No. 218-EN
3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

ceiling. If the car door was not fully open due to the counterweight bottoming out, the chains are too long and must be adjusted at the studs or some links must be removed to shorten the chains.

Finally adjust the chain studs with just slightly more tension (less slack) on the long chain to allow for greater chain stretch. The car door must move smoothly in the guide rails during its entire travel. Adjust the shoes (inward-outward) only if the car door panel is not square in the guide rails or if there is no side-to-side play. With the car door raised 75mm [3in] off the platform, check to see if car door panel hangs level. Adjust the chains to level the car door panel.

The car door panel should balance the counterweight at half-travel position. With the car door at half-travel open, manually push it further open and from the same position push it closed. Weight differential can usually be detected by this method. Add or remove the counterweight flats to achieve balance of the counterweight and the car door panel.

The car door panel must be exactly balanced (at half-travel position) by the counterweight to prevent the car door drifting open when the elevator car is in motion or from drifting closed at an inappropriate time.

6.7. CAR DOOR RUBBER BUMPERS

Bumpers are important to reduce noise and reduce car door wear and tear. The car door bottom bumpers can be adjusted by adding flat washers as spacers for proper positioning if the car platform is not level.

6.8. CAR DOOR CONTACT

When the car door is in the closed position the electrical car door contact must also be "made". This is activated by a roller cam attached to the top of the car door counterweight. The counterweight has a small degree of horizontal play. Ensure the car door contact will remain "made" by moving the counterweight back and forth.

Check that the car door contact stops the elevator when the car door is lifted up 50mm [2in] from its closed position. If there are two car doors on an elevator, the car door contacts usually wired in series. See elevator controller prints.

6.9. RETIRING CAM

Freight door interlocks are designed to be operated by a retiring cam. The retiring cam is mounted on the car. There is a connecting rod between the cam face and the retiring cam motor.

The cam motor is mounted above the car top height. The cam face assembly is mounted on the side of the car, vertically near the door opening centerline for biparting doors and lower down for slip up landing doors. Both have pre-drilled holes in the Peelle car door rail. Follow the installation drawings when you are installing the retiring cam. The retiring cam face should be mounted to the center of the interlock rollers horizontally and vertically when the car is at each floor. The interlock rollers must be adjusted so that when the cam is extended (by gravity), it unlocks the interlock. The cam must be set to fully unlock the interlock with over-travel.



Guide No. 218-EN
3 SECTION SLIDE-UP CAR DOOR
INSTALLATION GUIDE

The cam face is weighted so that the cam will drop while in the "no power" condition and unlock the door. The doors can be manually opened if the car is at a landing and there is no power to the retiring cam. When the cam motor is energized, it lifts (retires) the cam face to allow the interlock to lock the door.

The cam large pulley should be operated by hand to make sure that it does not bind or hang-up. The V-belt deflection should be set at 13mm [1/2in]. Adjust the motor position to achieve 13mm [1/2in] deflection.

The effective length of the connecting rod between the crank pulley and the cam face must be adjusted so that the rotation of the crank is limited. To adjust the cam rod length: manually hold the cam face fully up (retired); while held in this position, rotate the crank arm towards the center of the car; tighten the rod nuts with the crank held 90 degrees back (towards the center of the car) from the down direction. When powered the cam motor must then pick the cam rod toward the center of the car. If the direction of the lift is toward the front of the car, reverse the motor rotation by switching any two of the three motor power leads. The cam rod must pick toward the center of the car. The motor must pick up and stall when the cam is retired (picked up) under power. The cam face must drop easily when not under power.

Fixed cams are sometimes used instead of retiring cams with side-opposite-locks. Mechanical door locking must take place as the car travels away from the floor.

After installing the cam(s), run the car up slowly on inspection to check any retiring cam obstacles in the hoistway shaft.

6.10. PULL STRAPS

Pull strap(s) may be provided for each door and car door. Pull straps are mounted on the panel and hang down so that the operator may pull the car doors closed. Limiting the length of the straps ensures that they do not become a hazard during operation of the car.



DO NOT TIE KNOTS IN STRAPS OR CREATE LOOPS


Straps are required for manually operated vertically sliding car doors to ensure they can be conveniently closed. Car doors require one pull strap and biparting doors require two straps.

If supplied on power operated car doors, the straps will be tucked away behind a clip, and still be accessible in case of a power failure. Where pull straps have been provided on car doors conforming to ASME A17.1/CSA B44, 2008 addenda, a pull strap contact is provided and should be wired in series with door stop button contact to the Peelle door controller.



Guide No. 218-EN3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

7. CAB / CAR ENCLOSURE PREPARATION






Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

8. RAIL INSTALLATION






FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

9. SPREADER / OPERATOR SUPPORT






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

10. RAIL SPREADER & DIAGONAL BRACE






FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

GAUGE THE RAILS 11.




12



Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

12. SET THE RAILS





Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE


13. **BRACING RAILS TO CAR**





Guide No. 218-EN 3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

COUNTERWEIGHT ASSEMBLY 14.





15


Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

Nov 22 / 2019 Date:

15. COUNTERWEIGHT INSTALLATION

STEP 1






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

STEP 2



17




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE



18




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

16. IDLER / ENCODER INSTALLATION






TECHNICAL SUPPORT 1-800-787-5020 ext 275

19

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

17. OPERATOR / SPROCKET INSTALLATION






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

18. PANEL BUMPERS






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

19. UNLOADING THE PANELS






22

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

20. INSTALL THE UPPER PANEL






THE PEELLE COMPANY
REIGHT DOORS I CAR GATES I CAR ENCLOSURE:

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

21. INSTALL THE MIDDLE PANEL



24




FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

22. INSTALL THE LOWER PANEL



25




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

23. CHAIN CONNECTION DETAIL



26




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

24. PANEL ROPING SCHEMATIC






Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

25. CHAIN CONNECTION DETAILS



28




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE





THE PEELLE COMPANY


FREIGHT DOORS | CAR GATES | CAR ENCLOSURES

TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

26. REMOVE COUNTERWEIGHT STOP ANGLE






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

27. PULL STRAP INSTALLATION (MANUAL OPERATION)






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

28. CAR DOOR / CAR DOOR CONTACT



32



THE PEELLE COMPANY


FREIGHT DOORS | CAR GATES | CAR ENCLOSURES

TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

29. RETIRING CAM TOP ASSEMBLY






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

30. **RETIRING CAM BOTTOM ASSEMBLY**






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR **INSTALLATION GUIDE**

31. RETIRING CAM ROD INSTALLATION






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

32. FILLER ANGLES






THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES
TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

33. GOF MICRO SWITCH INSTALLATION



37




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

34. CAR DOOR PROXIMITY SENSOR (OPTIONAL)



38




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES TECHNICAL SUPPORT 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE

35. DOOR PROXIMITY SENSOR (OPTIONAL)



39




THE PEELLE COMPANY

FREIGHT DOORS | CAR GATES | CAR ENCLOSURES **TECHNICAL SUPPORT** 1-800-787-5020 ext 275

Guide No. 218-EN

3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE





Guide No. 218-EN3 SECTION SLIDE-UP CAR DOOR INSTALLATION GUIDE