



Elevator Requirements Prior to the Installation of Pelle Doors

- The elevator guide rails, platform and counterweight are installed
- The drive machine and controller are installed and connected for temporary usage
- The working elevator platform is operable by a hand-held pendant station
- The car enclosure is not installed
- Channel steel entrance frames are installed and set at the appropriate position relative to the car platform
- Temporary barricades are set up at each opening

